

Cyberphone-K V652SKMLR Quick Start Guide




This guide provides a quick reference for connecting your VoIPVoice Skype Cyberphone-K plus installing and using the software.

Please read the User Guide available on the CD ROM. It contains in depth information about installation and using advanced features. For technical support please email support@voipvoice.com, visit our website at www.voipvoice.com for Frequently Asked Questions or check the VoIPVoice forums at <http://forums.voipvoice.com>

Before continuing with the install, please make sure you have the following minimum requirements.

- A PC running Microsoft Windows 2000 or XP.
- 400MHz Processor (CPU).
- 128MB RAM.
- 15MB Free Hard Disk Space.
- One Free USB port (USB1.1 or USB2.0).
- An Internet connection (dialup: 33kbps minimum or broadband).

Connecting the VoIPVoice Skype Cyberphone-K Hardware



Plug the VoIPVoice Skype Cyberphone-K into a free USB socket on your computer or into a powered USB hub.

Windows will then start to detect plug and play devices.

Installing the Software

First insert the CD ROM into your computers CD ROM Drive the setup should now start automatically. If the CD Install does not start automatically, browse to the CD ROM Drive on your computer using **My Computer** or **Windows Explorer** and click *setup.exe* then simply follow the on screen instructions to complete the install.

Making a Call

Apart from the usual number buttons, there are some special buttons on the VoIPVoice Skype Cyberphone-K.



Hook switch button in the handset, use this for ending calls. Pressing this button is the same as replacing the handset and picking it back up again.



Dial button, press this button to start the call after dialling the number.



End call, press this button at the end of a call or replace the handset.



Mute button with LED indicator, press this button to mute the microphone on your handset, you will still be able to hear the caller but they won't be able to hear you.



Skype button, used for toggling between Start, Contacts, Dial and Calls List in Skype.



Volume control and used for selecting Skype contacts.

To make a Skype to Skype Call from your Contacts List

Lift the handset, use the + and - keys to scroll through the list, once the desired contact is highlighted simply press the dial key

To make a Skype to Skype call using speed dial

Ensure that you have associated speed dial numbers with your contacts. Simply enter the speed dial number followed by the dial key

To make a Skype Out call

Dial 00 followed by the country code, followed by the area code (excluding the first zero), followed by the phone number, then press dial.

Using VoIPVoice Dialling

Press the * key, type the first few letters of the contacts name using the letters on your phone keypad (e.g. for David you would dial 32843) You can make the software read a list of matching contacts by dialling just 1 or 2 letters followed by the # key. Let the voice guide you the rest of the way.

Receiving a Call

When the telephone rings, lift the handset to answer. There are other options such as Rejecting a call.